

5.25-Inch HDPE Bay Reservoir (CW-xxBR-5) Installation guide for threaded tube adaptors

1. Gather all required materials
 - HDPE Bay Reservoir
 - Tube adaptors and/or port plug
 - Plumbers GOOP™(recommended) or other sealant*

*WARNING if you use a silicone based sealant insure that it does not contain acetic acid. Acetic acid can cause HDPE to crack.



2. In accordance with the sealant instructions, coat the threaded portion of the tube adaptor.



3. Thread the tube adaptors and/or plug into the rear ports until there is 3/32-inch(2.40mm) or approximately the width of a nickel between the tube adaptor and reservoir ports. One or two threads should remain visible.

WARNING do not over tighten fittings



4. Allow the sealant to dry in accordance with the instructions. Once dry the assembly is ready to use.

